



GAE-168FB


P-01 CRANKCASE ASSY		
NO.	Parts Number	Description
1	GBJ.151.017.18.A051	Sway Bar Washer
2	68B.059.000.00.H046	Sway Bar Cotter Pin
3	68B.011.000.00.A247	Sway Bar
4	GBJ.019.004.00.H072	Bearing 6205
5	68B.001.001.19.A095	Crankcase
6	GBJ.147.037.16.A051	Drain Bolt
7	68B.026.001.00.A144	Oil Seal
8	68B.007.002.00.A003	Driven Gear,Regulator Assy
9	68B.021.001.00.A206	Oil Sensor
10	GBJ.147.006.16.A051	Bolt M6*16
11	GBJ.149.003.16.A051	Nut M10
12	68B.023.002.00.A210	Bottom Guard




P-02 CRANKCASE COVER ASSY		
NO.	Parts Number	Description
1	68B.002.001.19.A095	Crankcase Cover
2	68B.016.000.03.A003	Oil Dipsticks
3	68B.158.001.00.A221	Oil Seal
4	GBJ.147.025.16.A051	Bolt M8*32
5	68B.158.001.00.A221	Crankshaft Crankcase Gasket
6	GBJ.019.004.00.H072	Bearing
7	GBJ.146.002.00.A051	Dowel Pin



P-03 CYLINDER HEAD AND CYLINDER HEAD COVER ASSY		
NO.	Parts Number	Description
1	GBJ.147.005.16.A051	Bolt M6*12
2	68B.035.000.00.A210	Cylinder Head Cover
3	68B.160.001.00.A221	Cylinder Cover Gasket
4	68B.064.000.00.H014	Waste Pipe
5	GBJ.147.100.16.A051	Bolt M8*60
6	68B.004.000.00.A011	Cylinder Head Assy
7	68B.018.001.00.A045	Spark Plug Ngk
8	GBJ.147.079.16.A051	Stud Bolt M8*34
9	68B.159.002.00.A221	Cylinder Head Gasket
10	GBJ.146.003.00.A051	Dowel Pin 10*16
11	GBJ.147.075.16.A051	Stud Bolt M6*109
12	68B.034.000.00.A210	Wind Cover




P-04 CRANKSHAFT PISTON AND TIE ROD		
NO.	Parts Number	Description
1	68B.006.000.00.A098	Piston Coil Assy
2	68B.057.000.00.H046	Piston Cotter Pin
3	68B.005.000.00.A017	Piston
4	68B.012.000.00.A247	Piston Pin
5	68B.003.000.00.A010	Connecting Rod Assy
6	68B.029.005.00.A030	Crankshaft Assy
7	S.68B.674.001.00.A030	Semi-Circle Key




P-05 CAMSHAFT AND VALVE ROCKERS


NO.	Parts Number	Description
1	S.68B.660.001.00.A059	Lock Nut
2	S.68B.661.001.00.A059	Adjusting Nut
3	S.68B.659.001.00.A059	Rocker
4	S.68B.691.001.00.A059	Rocker Bolt
5	68B.010.000.00.A210	Pusher Guide
6	68B.032.000.00.A247	Pusher
7	68B.031.000.00.A247	Tappet
8	68B.030.001.00.A026	Camshaft Assy
9	68B.009.000.00.A247	Exhaust Valve
10	68B.008.000.00.A247	Intake Valve
11	68B.025.000.00.A144	Valve Oil Seal
12	68B.056.000.00.H046	Valve Spring
13	68B.014.000.00.A247	Exhaust Valve Spring Seat
14	68B.033.000.00.A247	Cap




P-06 CARBURETOR		
NO.	Parts Number	Description
1	70F.047.001.03.A035	Carburetor Assy
2	68B.161.001.00.A221	Inlet Gasket
3	68B.046.001.00.H014	Carburetor Connecting Block
4	68B.162.001.00.A221	Carburetor Gasket
5	68B.163.001.00.A221	Air Filter Gasket
6	S.68B.643.002.03.A035	Manual Choke




P-07 DUAL AIR FILTER		
NO.	Parts Number	Description
1	S.68B.695.001.00.H014	Nut
2	S.68B.692.001.00.H014	Air Filter Cover
3	S.68B.672.001.00.H014	Air Filter Sponge
4	GBJ.149.001.16.A051	Nut M6
5	S.68B.694.001.00.H014	Air Filter Seat




P-08 MUFFLER		
NO.	Parts Number	Description
1	GBJ.149.008.16.A051	Nut M8
2	GBJ.180.003.16.A051	Spring Washer $\Phi 8$
3	68B.051.001.00.A168	Muffler Assy
4	68B.164.001.00.A221	Outlet Pipe Gasket




P-09 RECOIL ASSEMBLY		
NO.	Parts Number	Description
1	S.68F.625.001.22.A191	Recoil Assembly
2	S.68B.624.001.22.A191	Fan Cover
3	68B.053.001.03.A206	Engine Stop
4	GBJ.147.003.16.A051	Bolt M6*8
5	GBJ.147.005.16.A051	Bolt M6*12




P-10 REGULATOR CONTROL SYSTEM		
NO.	Parts Number	Description
1	70F.060.001.00.H046	Backspring
2	GBJ.147.081.16.A051	Lock Bolt M6*21
3	68B.038.000.00.A210	Regulating Arm
4	GBJ.149.001.16.A051	Nut M6
5	70F.061.001.00.H046	Fine Regulating Spring
6	68B.063.000.00.H046	Pulling Rod
7	68B.036.002.00.A210	Accelerator Assy
8	GBJ.147.005.16.A051	Bolt M6*12



P-11 FLYWHEEL		
NO.	Parts Number	Description
1	GBJ.149.006.16.A051	Nut M14
2	68B.168.001.00.A191	Starting Flange
3	68B.045.001.00.H014	Flywheel Fan
4	68B.041.001.00.A005	Flywheel



P-12 IGNITION COIL		
NO.	Parts Number	Description
1	68B.042.001.00.A029	Igniton Assy
2	GBJ.147.008.16.A051	Bolt M6X25



P-13 FUEL TANK		
NO.	Parts Number	Description
1	S.68B.641.003.00.A123	Fuel Cap
2	GBJ.147.008.16.A051	Flange Bolt M6X25
3	TYJ.058.000.00.H046	Hose Clamp
4	TYJ.054.000.00.H149	Fuel Outlet Hose
5	GBJ.149.001.16.A051	Nut M6
6	68B.166.001.22.A123	Fuel Tank

